



Owners Manual



Snowbike[®] S8

Important: Read this manual before using your Snowbike!



Welcome

Congratulations for choosing a Bre^{nter} Original Snowbike[®].
Your new Snowbike[®] C4 offers unique features:

- light weight
- patented active full suspension system (front & rear)
- easy collapsability for a comfortable transport
- patented ski quick change system

To learn more and to increase your skill level we recommend to attend a Snowbike[®] “Reflex based Workshop”. For a detailed list of Snowbike Rent & Ride Partners please give us a call.

Warning

USE OF SNOWBIKE MAY BE HAZARDOUS. SERIOUS INJURY
MAY OCCURE.

Please do not operate your Snowbike[®] without prior
instruction and read this manual carefully.

No passengers allowed.

Weight limit 110 kg (250 lbs).

Snowbike[®] is a registered Trademark of Bre^{nter} Austria
Bre^{nter} is a registered Trademark of Bre^{nter} Austria.

US Patent No. 5863051 DE Patent Nr. 32 32 970
DE Patent Nr. 195 30 081 DE Patent Nr. 197 09 269
and other pending patents.

technical details are subject to change.



Things you should know



Fun

Winter sports offer a lot of variety and fun. Always be aware that sports in general may be risky. For your personal safety please make yourself confident with the responsibility code and owners manual.



Workshop

To control and enjoy your Snowbike® we highly recommend to attend a Snowbike Workshop with a professional Snowbike® trainer. How to load a Snowbike® onto the lift and various riding techniques will be taught. **Snowbike® a smile after every run is guaranteed.**



Responsibility code

Please find out about national or local regulations and laws before you operate your Snowbike®.



Health Care

Riding a Snowbike® is fun. If you have any health concerns, please consult your doctor first.



Warning

Check your Snowbike® prior to every run. Your Snowbike® is exclusively designed for use on groomed slopes only. Please stay on designated slope areas only. Always keep both hands on the handle bar and hold tight. Do not use your Snowbike® without footskis. No passengers allowed. Do not replace or change any original parts on the Snowbike® with non-Brenter parts. For your own safety and the safety of other slope users do not jump with your Snowbike®. Always stay in control of your speed.

Assembly

Parts list

- handle bar & grips & clamp
- front ski with quick change plate
- frame pre assembled
- rearski with clamps and quick change plate
- 1 pair of foot skis (optional)
- owners manual






Plate binding

- ① slide out black lever
- ② move toe and heel clip to adjust your shoe size



Boarder binding

- open both ladders
 - move in with heel first adjust boot in middle of binding
- ① close front ladder first
 - ② than close slide out black lever




Always use safety strap!

Step in binding (optional)

Adjust rear binding position by lifting tab ① and sliding binding along channel ②

Insert toe of boot into plate near tip and position heel over tabs of rear binding. Lower heel down until rear binding clamps boot.




Skistopper has to be on outside.

Assembly

Fold saddle backwards

Grab saddle at point (A) and fold back corresponding movement (1)




Handle bar

Grab handle bar at point (B) and slide onto steering column (movement 2)


Caution: handle bar has to be slid down all the way. Close quick lock.

Please control tight fit of quick lock before every run.




Rear Ski

Step onto rearski at point (C). Grab the frame at point (D) and the handle bar with your left hand point (E). Move the frame - parallel to the ground - forward (movement (3)).



Front Ski


Grab the handle bar at (F) and turn the front ski slightly to the left (move (4)). Rest the front ski to the floor (5). Step onto the frontski (G). Fold frame backwards (6).



Adjust saddle

open with only 2 turns screw (H). Push saddle in or Pull out to adjust your perfect sitting position.

Caution! do not pull out the saddle too far, a min of 12 cm has to stay in the tube. Do not move the thicker tube! Make sure to fix the screws after adjustment. Do not operate or change the saddle if you are not experienced.







Folding

Simply fold your Snowbike® up
for transport in car or gondola

- 1 Fold frontski back
- 2 Fold rear ski forward
- 3 Open quick lock and remove handle bar
- 4 Fold saddle forward
- 5 Hook footski with rear loop over handle bar



- ! Easy carrying
hold footski & handlebar in your left hand
carry snowbike frame in your right hand





Specifications

● **ready to ride**

length 211 cm
width 58 cm
seat height (M) 61 cm

● **folded up**

length 130 cm
width 14 cm
height 60 cm

● **net weight**

8 kg class

● **details**

aluminium Frame and components
active Suspension front & rear;

● **ski**

carving Cap ski

● **max rider weight** 110 kg (250 lbs)



Construction and materials may vary.
measurements are approximate and may vary with bike sizes.



NO PASSENGERS ALLOWED!

Your Snowbike[®] should be customized
to your body measurements.


How to ride

“The Brenter Reflex Based Methode”

Here are the basics: Do not control speed by using your footskis. Control your speed by skidding the rear ski using the techniques below. Once you got the basic technique, you can improve your riding technique to powder, mogules, carve and rebound. To improve faster, see our rent & ride partner and join a “reflex based method” workshop. Explore your talents - Snowbike®.


Basic sitting position

- knees together
- arms straight
- no weight on foot ski




Exercise 1

- lean head into the turn



Exercise 2


- lean head into the turn
- turn head to the inside -> rear ski skids
- practice skidding to control your speed
- do not put weight on your foot ski



Transport

T-bar, platter lift: stand upright Snowbike between your legs.


Stand upright, shoulders back on your foot skis. Snowbike between your legs.



Chair lift always use outside seats


When entering the loading zone, have your Snowbike on the outside already. Pick it up when you stop at the loading point and turn your head to the inside. When seated hook the bike with saddle on the armrest or behind the pole. Close the safety bar.

Always keep one hand on your bike!



Gondola always folded up inside

Within seconds your Snowbike® will be folded for easy transport in the gondola. Before entering lift line fold up Snowbike as shown on previous page. Take a seat with Snowbike® between your legs.



Please see one of our Rent&Ride partners to learn more on easy transportation procedures.



Responsibility Code

1. Always stay in control, and be able to stop or avoid other people or objects.
2. People ahead of you have the right of way. It is your responsibility to avoid them.
3. You must not stop where you obstruct a trail or are not visible from above.
4. Whenever starting downhill or merging into a trail, look uphill and yield to others.
5. Always use devices to help prevent runaway equipment.
6. Observe all posted signs and warnings. Keep off closed trails and out of closed areas.
7. Prior to using any lift, you must have the knowledge and ability to load, ride and unload safely.



Inspection

DATE

INSPECTION 1

DATE

INSPECTION 2

DATE

INSPECTION 3

DATE

INSPECTION 4

DATE

INSPECTION 5

DATE

INSPECTION 6

DATE

INSPECTION 7

DATE

INSPECTION 8



Please maintain your Snowbike[®] periodically and have it technically checked at least once a year.



send to:

Brener GmbH
ORIGINAL SNOWBIKE
Arnsdorferstr. 19-23
5110 Oberndorf
AUSTRIA

First Class
Postage Required
Post Office will
not deliver without
proper postage.

Product Registration S8

For Your Safety

Registering your product will allow us to contact you in the unlikely event a safety notification is required under the Consumer Product Safety Act.

To Confirm Ownership

In case of an insurance loss such as fire, flood or theft, registration can serve as your proof of purchase.

First name _____

Family Name _____

Street _____

CITY _____

ZIP CODE _____

Phone / Fax _____

E-mail _____

date of purchase: _____ please include receipt

date, signature _____

Fax: +43-6272-7777-22

www.snowbike.com